

Hydro-View / Hydro-Hub EtherNet/IP Configuration Guide

To re-order quote part number:	HD0922
Revision:	1.2.0
Revision date:	July 2025

Copyright

Neither the whole or any part of the information contained in nor the product described in this documentation may be adapted or reproduced in any material form except with the prior written approval of Hydronix Limited, hereinafter referred to as Hydronix.

© 2025

Hydronix Limited
Units 11 & 12 Henley Business Park
Pirbright Road
Normandy
Guildford
Surrey GU3 2DX
United Kingdom
All rights reserved

CUSTOMER RESPONSIBILITY

The customer in applying the product described in this documentation accepts that the product is a programmable electronic system which is inherently complex and which may not be completely free of errors. In doing so the customer therefore undertakes responsibility to ensure that the product is properly installed commissioned operated and maintained by competent and suitably trained persons and in accordance with any instructions or safety precautions made available or good engineering practice and to thoroughly verify the use of the product in the particular application.

ERRORS IN DOCUMENTATION

The product described in this documentation is subject to continuous development and improvement. All information of a technical nature and particulars of the product and its use including the information and particulars contained in this documentation are given by Hydronix in good faith.

Hydronix welcomes comments and suggestions relating to the product and this documentation

ACKNOWLEDGEMENTS

Hydronix, Hydro-Probe, Hydro-Mix, Hydro-Skid, Hydro-View and Hydro-Control are Registered Trade Marks of Hydronix Limited

CUSTOMER FEEDBACK

Hydronix is continually looking to improve not only its products but also the services that we offer to our customers. If you have any suggestions about how we can do this or if you have any other feedback that would be helpful please complete our short form at www.hydronix.com/contact/hydronix_feedback.php.

If your feedback is concerning an Atex certified product or associated service it would be very helpful for you to give us your contact details and the model number and serial number of the product if possible. This will enable us to contact you with any relevant safety advice should this be necessary. It is not obligatory to leave your contact details and any information will be treated as confidential.

Hydronix Offices

UK Head Office

Address: Units 11 & 12 Henley Business Park
Pirbright Road
Normandy
Guildford
Surrey GU3 2DX
United Kingdom

Tel: +44 1483 468900

Fax: +44 1483 468919

Email: support@hydronix.com
sales@hydronix.com

Website: www.hydronix.com

North American Office

Covers North and South America, US territories, Spain and Portugal

Address: 692 West Conway Road
Suite 24, Harbor Springs
MI 47940
USA

Tel: +1 888 887 4884 (Toll Free)

+1 231 439 5000

Fax: +1 888 887 4822 (Toll Free)

+1 231 439 5001

European Office

Covers Central Europe, Russia and South Africa

Tel: +49 2563 4858

Fax: +49 2563 5016

French Office

Tel: +33 652 04 89 04

Revision history

Revision No	Software Version	Date	Description of Change
1.0.0		Sept 2020	First release
1.1.0		August 2021	Updated Connection Diagrams
1.2.0		July 2025	DCR 7998 - Added IO mappings

Table of Contents

Chapter 1 Introduction.....	11
Chapter 2 Electrical Wiring.....	13
1 Hydronix EtherNet/IP Module.....	13
2 Wiring	14
Chapter 3 Hydro-Hub Setup.....	17
1 Configure the Hydro-Hub Fieldbus Address	17
Chapter 4 I/O Data	21
1 Example Transactions.....	25
Appendix A Document Cross Reference	29
1 Document Cross Reference	29

Table of Figures

Figure 1: Hydro-Hub EtherNet/IP Module	11
Figure 2: Hydro-Hub (L), Hydro-View (R)	11
Figure 3: System Overview	12
Figure 4: EtherNet/IP Module.....	13
Figure 5: Protection Cover	13
Figure 6: Installing the Hydro-Hub EtherNet/IP Module.....	13
Figure 7: Hydro-Hub EtherNet/IP Module Installed	13
Figure 8: Star Topology.....	14
Figure 9: Ring Topology.....	14
Figure 10: Hydro-Hub Settings.....	17
Figure 11: Hydro-Hub EtherNet/IP Address.....	17
Figure 12: Accessing the EtherNet/IP Module's Configuration Tool.....	17
Figure 13: Accessing the EtherNet/IP Module's Configuration Tool.....	18
Figure 14: EtherNet/IP Module's Configuration Tool Main Screen	18
Figure 15: EtherNet/IP Configuration Screen	18
Figure 16: Notification pop-up window	19
Figure 17: Hydro-Hub EtherNet/IP Module Correctly Configured.....	19
Figure 18: Connection Configuration	21
Figure 19: Input Register.....	26
Figure 20: Section of the Input Register	27

This guide details the installation and configuration of the optional Hydronix Hydro-Hub EtherNet/IP Module. The module enables EtherNet/IP communication between the Hydro-Hub/Hydro-View and a EtherNet/IP Scanner.




Figure 1: Hydro-Hub EtherNet/IP Module

Using the Hydronix EtherNet/IP module will provide direct access to any Hydronix Sensor connected to the Hydro-Hub/Hydro-View network from the PLC.





Figure 2: Hydro-Hub (L), Hydro-View (R)

Previous knowledge of EtherNet/IP, Allen-Bradley PLCs, Studio 5000 and RSLinx are required as this document is intended as a basic guide only.

For detailed Hydro-Hub/Hydro-View instructions see the Hydro-Hub/Hydro-View user guide HD0864

All references to a Hydro-Hub EtherNet/IP Module in the guide are valid for the Hydro-Hub and Hydro-View hardware. The electrical connections and configuration of the Hydro-Hub and Hydro-View are identical.

**Figure 3: System Overview**

1 Hydronix EtherNet/IP Module

To enable EtherNet/IP communication with the Hydro-Hub/Hydro-View the optional Hydronix EtherNet/IP Module must be installed.



Figure 4: EtherNet/IP Module

1. Switch off the Hydro-Hub/Hydro-View
2. Remove the protection cover from the Hydro-Hub/Hydro-View



Figure 5: Protection Cover

3. Insert the Hydro-Hub EtherNet/IP Module as show in the Figure 6. Ensure the connector is correctly positioned.




Figure 6: Installing the Hydro-Hub EtherNet/IP Module

4. Tighten the two anti-tamper screws.




Figure 7: Hydro-Hub EtherNet/IP Module Installed

2 Wiring

The Hydronix EtherNet/IP module supports Star and Ring topologies.

2.1 Star Topology

When using a Star topology, the PLC (controller) and all Hydronix EtherNet/IP Modules are connected to a central network switch.



Figure 8: Star Topology

2.2 Ring Topology

When using a ring topology, the PLC (controller) and all Hydronix EtherNet/IP Modules are connected in a ring



Figure 9: Ring Topology

Note: To enable remote access to the Hydro-Hub/Hydro-View, the main ethernet communication port must also be connected to the network switch (connection not shown).

2.3 Cables

The Hydronix EtherNet/IP Module utilises a RJ45 connector. Suitable cables are:

- Category 5
- Category 5e
- Category 6
- Category 6e

To avoid electrical interference all cabling must be run separately from any mains and motor cabling. A segregation of at least 200mm between the EtherNet/IP cabling and any high voltage/current wiring must be provided.

In situations where the 200mm segregation cannot be provided, for example when cables must cross, ensure they pass at 90° (never parallel).

In areas at risk of lightning strikes, protection should be provided to shield the EtherNet/IP module and the Hydro-View/Hydro-Hub from damage.

Note: For additional EtherNet/IP cabling guidance see the appropriate EtherNet/IP standards documentation.

All wiring must be performed by persons holding the required qualifications for the local area.

The only configuration required in the Hydro-Hub to enable EtherNet/IP communication is the Fieldbus Address. The Fieldbus address must be the fixed I.P address that is targeted by the Scanner initiating the Class 1 connection.

1 Configure the Hydro-Hub Fieldbus Address

Select Settings from the main menu (It is assumed for this step that a user has logged in as an engineer. See HD0864 for details)



Figure 10: Hydro-Hub Settings

Note the I.P address in the 'Field bus address' and type this in to a web browser.

The screenshot shows the 'I.P Address Settings' tab in the Hydro-Hub interface. The 'FieldBus Address' field is highlighted with a green border and contains the value '0.0.0.0'. Other settings include Units (U.S Imperial), Language (English), Datasheet Version (HYDRONIX.EDS 1.0.0), OS Version (Linux 4.14.70-v7+), and Software Version (Hydro-Net 1.1.0.8). There are buttons for 'Upgrade', 'Backup', 'Restore', and 'Save'.

Figure 11: Hydro-Hub EtherNet/IP Address

To change the EtherNet/IP module's IP configuration enter the current IP address, shown in the 'Fieldbus Address' into a web browser (see Figure 12).



Figure 12: Accessing the EtherNet/IP Module's Configuration Tool

A notification field might pop up informing that the device does not support a secure connection; click the "Continue to site" button.



172.16.99.133 doesn't support a secure connection

- **Attackers can see and change** information you send or receive from the site.
- **It's safest to visit this site later** if you're using a public network. There is less risk from a trusted network, like your home or work Wi-Fi.

You might also contact the site owner and suggest they upgrade to HTTPS. [Learn more about this warning](#)

Continue to site

Go back

Figure 13: Accessing the EtherNet/IP Module's Configuration Tool

The browser will display the main screen of the configuration tool (see Figure 14).

MODULE	Identification
Overview	Module name: Hydro-Hub Ethernet/IP Module
Parameters	Serial number: 11223344
NETWORK	FW version: 1.01
Status	Uptime: 0 days, 0h:36m:34s
Configuration	CPU Load: 20%
SERVICES	
SMTP	

Figure 14: EtherNet/IP Module's Configuration Tool Main Screen

Click the "Configuration" button to enter the configuration page (arrow No 1 on Figure 15). Amend the IP details as required in the section pointed out by arrow No 2 and press the "Save settings" button (arrow No 3).

MODULE	IP Configuration
Overview	DHCP: Enabled
Parameters	IP Address: 172.16.99.134
NETWORK	Subnet Mask: 255.255.255.0
Status	Gateway Address: 172.16.99.254
Configuration	Host Name:
SERVICES	Domain name: hydronix.local
SMTP	DNS Server #1: 194.168.4.123
	DNS Server #2: 194.168.8.123
	Save settings

Ethernet Configuration	
Port 1	Auto
Port 2	Auto
Save settings	

Figure 15: EtherNet/IP Configuration Screen

A prompt window will appear to confirm that the configuration was performed (see Figure 16). Press the OK button to accept.




Figure 16: Notification pop-up window

Reboot the device for the changes to take effect. The new address of the EtherNet/IP module will be visible in the Fieldbus Address field on the System Settings screen.

After the Fieldbus address has been changed the Hydro-Hub must be powered down and then restarted. If the Hydro-Hub is connected to the network and the Scanner is configured correctly both lights on the Hydro-View EtherNet/IP module will be green.




Figure 17: Hydro-Hub EtherNet/IP Module Correctly Configured

The Hydronix EtherNet/IP module must have a class 1 connection established to run. The connection configuration is as shown in Figure 18.

▼ Connection Configuration

Originator to Target (O → T) parameters		Target to Originator (T → O) parameters	
☒ Instance ID	150	☒ Instance ID	100
☐ Tag name		☐ Tag name	
Data size	12 ☐	Data size	70 ☐
	☒ Run/idle header		☐ Run/idle header
Packet rate (ms)	100	Packet rate (ms)	100
Production inhibit (ms)	0	Production inhibit (ms)	0
Transport type	Point to point	Transport type	Point to point
Data size type	Fixed size	Data size type	Fixed size
Priority	Scheduled	Priority	Scheduled
Forward open parameters		Misc. options	
Transport trigger	Cyclic	☒ Keep TCP connection active	
Timeout multiplier	16	☐ Redundant owner	
Configuration data			
Instance	3	 	
Size	0		

Figure 18: Connection Configuration

The I/O mappings are defined in **Table 1**

Value	Input Bytes	Length In Bytes
Filtered Unscaled F	0-3	4
Filtered Unscaled V	4-7	4
Filtered Unscaled E	8-11	4
Filtered Moisture Mode F	12-15	4
Filtered Moisture Mode V	16-19	4
Filtered Moisture Mode E	20-23	4
Unscaled Average Mode F	24-27	4
Unscaled Average Mode V	28-31	4
Unscaled Average Mode E	32-35	4
Moisture Average Mode F	36-39	4
Moisture Average Mode V	40-43	4
Moisture Average Mode E	44-47	4
Electronics Temp	48-51	4
Resonator Temp	52-55	4
Material Temp	56-59	4
Digital Outputs	60-61	2
Averaging Status	62-63	2
Updated	64-65	2
Available Sensors	66-67	2
Search Status	68-69	2
Value	Output Bytes	Length In Bytes
Sensor Address	0-1	2
Update Values	2-5	4
Update Trigger	6-7	2
Activate Averaging	8-9	2
Search Network	10-11	2

Table 1: I/O Mapping

The I/O data available using the Hydronix EtherNet/IP module is detailed in **Table 2**.

Module Name	Input/output	Data Type	Description	Data Range
Sensor Address	Output	Word	Node address of the Connected sensor	1 to16 16#0001 to 16#0010
Update Values	Output	DWord	Configures the Update Mode to enable reading of the Averaging Status and/or the Digital Outputs for each connected sensor	16#0000_0000= None 16#0000_0001=Digital Outputs 16#0000_0002=Averaging Status 16#0000_0003=Both Sensor Address must be set to 16#0000 for this request to work
Update Trigger	Output	Word	Update Trigger initiates a sensor update command	The Hydro-Hub will initiate the communication with a sensor whenever the Update Trigger value changes. (Positive Edge)
Activate	Output	Word	Activate the averaging	Each bit in the 16bit word will

Averaging			in a single or multiple connected sensors	active the sensor with the corresponding node address (1-16) Sensor Address must be set to 16#0000 for this request to work
Filtered Unscaled F	Input	DWord	Floating point Number 2 decimal place precision. Sensor output value "Filtered Unscaled Mode F"	
Filtered Unscaled V	Input	DWord	Floating point Number 2 decimal place precision. Sensor output value "Filtered Unscaled Mode V"	
Filtered Unscaled E	Input	DWord	Floating point Number 2 decimal place precision. Sensor output value "Filtered Unscaled Mode E"	
Filtered Moisture F	Input	DWord	Floating point Number 2 decimal place precision. Sensor output value "Filtered Moisture Mode F"	
Filtered Moisture V	Input	DWord	Floating point Number 2 decimal place precision. Sensor output value "Filtered Moisture Mode V"	
Filtered Moisture E	Input	DWord	Floating point Number 2 decimal place precision. Sensor output value "Filtered Moisture Mode E"	
Unscaled Average F	Input	DWord	Floating point Number 2 decimal place precision. Sensor output value "Average Unscaled Mode F"	
Unscaled Average V	Input	DWord	Floating point Number 2 decimal place precision. Sensor output value "Average Unscaled Mode V"	

Unscaled Average E	Input	DWord	Floating point Number 2 decimal place precision. Sensor output value "Average Unscaled Mode E"	
Moisture Average F	Input	DWord	Floating point Number 2 decimal place precision. Sensor output value "Average Moisture Mode F"	
Moisture Average V	Input	DWord	Floating point Number 2 decimal place precision. Sensor output value "Average Moisture Mode V"	
Moisture Average E	Input	DWord	Floating point Number 2 decimal place precision. Sensor output value "Average Moisture Mode E"	
Electronics Temp	Input	DWord	Floating point Number 2 decimal place precision. Sensor output value "Electronic Temperature"	
Resonator Temp	Input	DWord	Floating point Number 2 decimal place precision. Sensor output value "Resonator Temperature"	
Material Temp	Input	DWord	Floating point Number 2 decimal place precision. Sensor output value "Material Temperature"	
Digital Outputs	Input	Word	Current status of the connected sensor(s) digital output	Each bit in the 16bit word will indicate the digital output status of the sensor with the corresponding node address (1- 16)
Averaging Status	Input	Word	Averaging status of the connected sensors	Each bit in the 16bit word will indicate the averaging status of the sensor with the corresponding node address (1- 16)
Updated	Input	Word	Updated is incremented when the Hydro-Hub has completed a message transaction	Rolling increment from: 16#0001 to 16#00FF If an error has occurred Updated will be set as: 16#0000

Available Sensors	Input	Word	Current sensors available on the network	Each bit in the 16bit word represents a sensor node address (1-16)
Search Status	Input	Word	Indicates if a search of the sensor network is in progress	0= No search in progress 1= Search in progress
Search Network	Output	Word	Start a search of the network	1= Start Search Increment the Trigger Word to initiate the search

Table 2: Hydronix EtherNet/IP Mapping

1 Example Transactions

To retrieve data from a sensor, a Search Network command must be completed. A search of the network is automatically started when the Hydro-View/Hydro-Hub is switched on. If a new sensor is added to the network a new search, using the Hydro-View/Hydro-Hub, must be performed. Alternatively, the network can be searched using the Search Network command.

1.1 Search Network

To initiate a search of the sensor network, set “Search Network” to 1 and increment the “Update Trigger” word. During the search cycle the “Search Status” word will be set to 1. Once the search has completed the “Search Status” word will return to 0.

The available sensors on the network are indicated by the “Available Sensors” word. Each bit in the “Available Sensors” word is set if a sensor is available. Each bit represents a sensor node address (1-16). The LSB represents address 1.

The following message shows there are 5 sensors on the network. The available sensors have node address: 1, 5, 9, 10 and 16.

1	0	0	0	0	0	1	1	0	0	0	1	0	0	0	1
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

1.2 Current Digital output status

To retrieve the current digital output status the “Sensor Address” output must be set to 0. The “Status Update Value” is set to 16#0000_0001 and the “Trigger” bit is incremented. Each bit of the 16bit “Digital Outputs” input is set to represent a sensor on the network based on the node address. The “Update Status” value will be incremented by 1 on completion of the request.

The following message indicates that the digital outputs on sensors 3, 12 and 16 are active.

1	0	0	0	1	0	0	0	0	0	0	0	0	1	0	0
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

1.3 Current Averaging Status

To retrieve the current “Averaging Status” of the sensors on the network the “Sensor Address” output must be set to 16#0000. “Update Values” is set to 16#0000_0002 and the “Update Trigger” bit is incremented. Each bit of the 16bit “Averaging Status” is set to represent a sensor

on the network based on the node address. The “Updated” value will be incremented by 1 on completion of the request.

The following message indicates that sensors 1, 2, 3 and 8 are currently averaging.

0	0	0	0	0	0	0	0	0	1	0	0	0	0	1	1	1
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

1.4 Activate Averaging

To command a sensor to start averaging the “Sensor Address” output must be set to 16#0000. The averaging for a sensor is configured by setting the appropriate bit in the 16bit “Activate Averaging” output. The “Update Trigger” bit is then incremented. The “Updated” value will be incremented by 1 on completion of the request. The “Activate Averaging” message is sent every time the “Trigger” is incremented and the sensor address is also set to 0.

The following message will start averaging a sensor with a node address of 1.

0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

To stop averaging the previously active bit is set to 0 and the “Trigger” bit incremented.

0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

1.5 Sensor Live Values

To retrieve the current live values from a sensor the “Sensor Address” value must be set to match the sensor node address (Sensor Address 1 will be 0 in Output Byte 0 and 1). The command is activated by changing the value in the “Update Trigger” word. The “Updated” value will be incremented by 1 on completion of the request. “Updated” will roll over to 0 once a value of 255 is reached.

Live values are written to the input bytes shown in **Table 1**. To use these values it is necessary to copy the 4 bytes (SINT datatype) into a REAL datatype. This can be achieved using the COP function.



Figure 19: Input Register




Figure 20: Section of the Input Register

Figure 19 shows part of the input register. **Table 1** shows that the Filtered Unscaled Mode F value is held in bytes 0-3. In the COP function shown in Figure 20 the register data is copied to a REAL variable named 'FilteredUnscaledF'. The length is 4 bytes

1 Document Cross Reference

This section lists all of the other documents that are referred to in this User Guide. You may find it beneficial to have a copy available when reading to this guide.

Document Number	Title
HD0864	Hydro-View / Hydro-Hub User Guide

Index

Electrical Wiring		
Wiring	14	
Fieldbus Address	17	
Hydronix EtherNet/IP Module.....	11, 13	
I/O Parameters		
Current Averaging Status	25	
Current Digital output status.....	25	
Data Types	22	
Search Network.....	25	
Sensor Address.....	22	
Sensor Live Values	26	
Set Averaging.....	26	
Status Update Value	22	
Trigger	22	
Update Status	24	
System Overview	12	