



Hydronix

Scalable Current Loop Display User Guide



To re-order quote part number:	HD0475
Revision:	1.5.0
Revision date:	March 2026

Copyright

Neither the whole or any part of the information contained in nor the product described in this documentation may be adapted or reproduced in any material form except with the prior written approval of Hydronix Limited, hereinafter referred to as Hydronix.

© 2026

Hydronix Limited
Units 11-12,
Henley Business Park
Pirbright Road
Normandy
Surrey
GU3 2DX
United Kingdom

Company Number: 01609365 | VAT Number: GB384155148

All rights reserved

CUSTOMER RESPONSIBILITY

The customer in applying the product described in this documentation accepts that the product is a programmable electronic system which is inherently complex and which may not be completely free of errors. In doing so the customer therefore undertakes responsibility to ensure that the product is properly installed commissioned operated and maintained by competent and suitably trained persons and in accordance with any instructions or safety precautions made available or good engineering practice and to thoroughly verify the use of the product in the particular application.

ERRORS IN DOCUMENTATION

The product described in this documentation is subject to continuous development and improvement. All information of a technical nature and particulars of the product and its use including the information and particulars contained in this documentation are given by Hydronix in good faith.

Hydronix welcomes comments and suggestions relating to the product and this documentation

ACKNOWLEDGEMENTS

Hydronix, Hydro-Probe, Hydro-Mix, Hydro-Skid, Hydro-View and Hydro-Control are Registered Trade Marks of Hydronix Limited

CUSTOMER FEEDBACK

Hydronix is continually looking to improve not only its products but also the services that we offer to our customers. If you have any suggestions about how we can do this or if you have any other feedback that would be helpful please complete our short form at www.hydronix.com/contact/hydronix_feedback.php.

If your feedback is concerning an Atex certified product or associated service it would be very helpful for you to give us your contact details and the model number and serial number of the product if possible. This will enable us to contact you with any relevant safety advice should this be necessary. It is not obligatory to leave your contact details and any information will be treated as confidential.

Hydronix Offices

UK Head Office

Address: Units 11-12,
Henley Business Park
Pirbright Road
Normandy
Surrey
GU3 2DX

Tel: +44 1483 468900

Email: support@hydronix.com
sales@hydronix.com

Website: www.hydronix.com

North American Office

Covers North and South America, US territories, Spain and Portugal

Address: 692 West Conway Road
Suite 24, Harbor Springs
MI 47940
USA

Tel: +1 888 887 4884 (Toll Free)
+1 231 439 5000

Fax: +1 888 887 4822 (Toll Free)
+1 231 439 5001

European Office

Covers Central Europe, Russia and South Africa

Tel: +49 2563 4858
Fax: +49 2563 5016

French Office

Tel: +33 652 04 89 04

Revision history

Revision No	Software Version	Date	Description of Change
1.0.0		April 2011	First Release
1.1.0		December 2011	Default factory settings added
1.2.0		April 2012	Wiring diagram for Thermo-Tuff added
1.3.0		November 2014	Reference to Hydro-Com versions > 1.80 added
1.4.0		June 2017	Updated Menu structure. Reference to Hydro-Com HS0099 v2.5.0 added
1.5.0		March 2026	Updated address Added customer feedback paragraph

Table of Contents

Chapter 1 Introduction.....	11
1 Introduction.....	11
2 Safety	11
Chapter 2 Mechanical Installation.....	13
1 Mounting Advice.....	13
Chapter 3 Electrical Installation	15
1 Wiring Advice	15
2 Electrical Connections.....	15
Chapter 4 Scalable Current Loop Display Setup	19
1 Setting the unit for use with Hydronix sensors.....	19
Chapter 5 Hydronix Sensor Setup	23
Chapter 6 Technical Specifications.....	25
1 Equipment Specifications	25
2 Default Factory Settings	25
Chapter 7 Troubleshooting.....	27
Appendix A Document Cross Reference	29
1 Document Cross Reference.....	29

Table of Figures

Figure 1: The panel cut-out needed for mounting the display	13
Figure 2: Re-fitting the U-Bracket	13
Figure 3: Side view of Scalable Current Loop Display installed in an enclosure	14
Figure 4: The Scalable Current Loop Display showing wiring connector location	15
Figure 5: Scalable Current Loop Display connections at rear of unit	15
Figure 6: Basic connections in 0-20 or 4-20 mA mode	16
Figure 7: Basic connections in 0-10v mode	16
Figure 8: Connecting in series with a PLC current input	16
Figure 9: Connecting in parallel with a PLC voltage input	17
Figure 10: Connections for 2-wire 4-20 mA mode (eg. Hydronix Thermo-Tuff temperature sensor) ...	17
Figure 11: Scalable Current Loop Display connections	19
Figure 12: Selecting the Language	19
Figure 13: Selecting the Drift Cancellation	19
Figure 14: Selecting the Boot-up Sequence	20
Figure 15: Selecting the Tare	20
Figure 16: Selecting the Delay	20
Figure 17: Selecting the calibration source	20
Figure 18: Set zero range value	21
Figure 19: Set full range value	21
Figure 20: Brightness settings	22
Figure 21: The sensor configuration page	23
Figure 22: The sensor configuration page with the output High and Low %	24

1 Introduction

This user guide is relevant for Scalable Current Loop Display units with the model number IL4-P-R-DC. For all other models see the relevant user guide provided.

The Scalable Current Loop Display unit is a cost effective method of displaying an analogue signal, such as the analogue output from a sensor.

One Scalable Current Loop Display unit is required for each sensor. The installer will need to provide an enclosure for the Scalable Current Loop Display and a power supply and associated connection terminals. The Scalable Current Loop Display is powered from a 24v DC power supply which may be the same supply that is providing the power to the sensor.

Sensor configuration and diagnostics is performed using Hydronix Hydro-Com software which can be run on a PC-compatible computer running Microsoft Windows XP service pack 3 or later.

Communications from the PC to the sensor can be achieved via USB (using a Hydronix USB Sensor Interface Module), via RS232 (using a Hydronix RS232 to RS485 converter) or via Ethernet (Using a Hydronix Ethernet Adapter Kit).

The sensor can be configured to output using either the 0-20mA or 4-20mA mode. Compatibility mode should not be used.

2 Safety



Please read this manual and all warnings. Install the Scalable Current Loop Display unit accordingly or severe electrical damage may occur to you or the device.

Check the supply voltage needed, the Scalable Current Loop Display is rated for 11 to 30v DC and is recommended to be used with Hydronix Part number 0116. The power supply must have an anti-surge (T) Fuse rated at 2A for DC supplies in the Range 11-30VDC.



The Scalable Current Loop Display is not designed to be installed in an area in which moisture and dust are present, unless mounted in a suitable enclosure. The unit should not be mounted in direct sunlight or high heat (>60°C) may cause damage as well.



Do not touch the internal or external connections while power is on. Electrical shock which may be lethal can occur.



Make sure all screw terminals are tight before the power is switched on.



Clean the front panel of the Scalable Current Loop Display with a soft, damp cloth. If cleaning is required behind the front panel then use a **dry** cloth.

1 Mounting Advice

The Scalable Current Loop Display should be installed in a suitable protective electrical control enclosure according to local wiring regulations. Space must be allowed in the enclosure to allow adequate air circulation to ensure the unit temperature is always kept below 60°C.




Figure 1: The panel cut-out needed for mounting the display

To fit the Scalable Current Loop Display, remove the two rear bracket screws and safely store them and the U-Bracket for later refitting.

Cut a hole in the enclosure or panel to the dimensions specified in Figure 1. Insert the Scalable Current Loop Display through the cut-out in the enclosure and then re-fit the U-Bracket to firmly clamp in place. Check that the gasket is evenly pinched between the front bezel and the enclosure front.




Figure 2: Re-fitting the U-Bracket

Figure 3 shows of the Scalable Current Loop Display from the side and shows the placement of the gasket.




Figure 3: Side view of Scalable Current Loop Display installed in an enclosure

1 Wiring Advice

The installation must be undertaken by a suitably qualified person and must conform to any local regulations.

The unit uses four detachable screw terminal connectors, as shown in Figure 4 below. These should be connected using standard multi strand equipment cable with a specification of at least the following:

Air Temperature Rating:	90°C continuous
Gauge Wire and screw Torque:	22 gauge to 16 gauge multi-strand and 0.8 Nm (7.0 lb/in) torque
Voltage Rating:	Wire should have insulation rating of 380V continuous




Figure 4: The Scalable Current Loop Display showing wiring connector location

Hydronix recommends Multi-Strand cable that is shielded with the screen connected at the plant end only. Cable should be routed away from any high voltage lines which may cause Electrical Noise interference.

2 Electrical Connections

Connections to the unit are made using the four detachable screw terminal connectors on the rear of the Scalable Current Loop Display. The description of the connections used for installation with Hydronix sensors is given in Figure 5.




Figure 5: Scalable Current Loop Display connections at rear of unit

As the analogue output of a Hydronix sensor is configurable, the actual connection wiring is dependent on the installation required. The next pages show wiring diagrams for each of the options including wiring in conjunction with a control system PLC input.

Figure 6 gives the connection details if the output is being used in either the 0-20mA or 4-20mA current modes.




Figure 6: Basic connections in 0-20 or 4-20 mA mode

Figure 7 shows the connection details if the output is connected using the 0-10v mode.




Figure 7: Basic connections in 0-10v mode

Figure 8 shows installation in series with a PLC current input. This can be used to provide a slave display whilst reading the sensor into a control system




Figure 8: Connecting in series with a PLC current input

Figure 9 shows how to connect in parallel with a PLC voltage input to provide a slave display whilst reading into a control system.




Figure 9: Connecting in parallel with a PLC voltage input

Figure 10 gives the connection details if a sensor is loop powered (2 wire) with the output in 4-20mA current mode.




Figure 10: Connections for 2-wire 4-20 mA mode (eg. Hydronix Thermo-Tuff temperature sensor)

1 Setting the unit for use with Hydronix sensors

To make changes to the basic configuration of the unit, the calibration switch on the rear of the Scalable Current Loop Display must be set to off (switch up).




Figure 11: Scalable Current Loop Display connections

1.1 Initial Setup

Press the 2 right hand buttons at the same time (marked Output and Alarms). This gives access to the language option. Press the up and down buttons to select the desired language then press the right hand button to accept (marked OK).




Figure 12: Selecting the Language

The next screen allows configuration of the drift cancellation option which should be left at the default value of "DRIFT 0". Press the right hand button to accept (marked OK).



Figure 13: Selecting the Drift Cancellation

The next screen shows the boot option, which can be set using the arrow keys to "BOOT 1". Pressing the right hand button (marked OK) will accept this.

Meter Bootup routine

1. Activates all digit segments
2. Runs up and down brightness settings
3. Displays model number and installed options
4. Displays firmware version
5. Displays calibration audit number.
6. Goes to meter mode



1. Activates all digit segments
2. Runs up and down brightness settings
3. Displays model number and installed options
4. Goes to meter mode



1. Goes immediately to meter mode

Figure 14: Selecting the Boot-up Sequence

The next screen allows selection of the Tare Memory function. This should be set to “TARE N”. Pressing the right hand button (marked OK) will accept.

Tare Memory**Figure 15: Selecting the Tare**

The next screen allows you to change the menu timeout delay. This can be left at the default value of 10 seconds. Pressing the right hand button (marked OK) will accept this.

**Figure 16: Selecting the Delay**

The next screens enable the configuration of the logic input functions (CC.1, CC.2 and CC.3). These are not used when connecting a Hydronix sensor and can be left as default. Press the right hand button (marked OK) until the main display is shown.

Once the initial settings have been completed it is possible to setup the calibration mode and parameters.

1.2 Theoretical Calibration mode setup**Figure 17: Selecting the calibration source**

Pressing the two buttons on the left (marked “Set 1” and “Set 2”) gives access to the calibration settings. The first option selection is for the calibration source. After “CAL.Src” is displayed for a few seconds, the unit allows either “THEOR” or “DIRECT” to be selected using the arrow keys. Press the up and down buttons to change the to “THEOR” and then press the right hand button (marked OK) to accept this.

The next screen configures the input type. After displaying “Input” briefly, the unit will give the option to select between either the voltage (“dc U”) or current (“dc A”) mode. Press the up and down buttons to change the input type and then press the right hand button (marked “OK”) to accept.

The unit will then return to the main numeric display.

1.3 Setting up the zero range value



Figure 18: Set zero range value

To enter the setup for the zero range parameters, the left hand button (marked “Set 1”) must be held in until the display shows first “THEOR”, then “dc A” or “dc U”, and then the parameter name to be changed. After this the display will read “In Lo”, and finally the zero input setting in mA. The arrow buttons can be used to set the currently highlighted digit and the left hand button (marked “Digit”) can be used to move to the next digit. When the value is correct the right hand button (marked “OK”) can be used to confirm the entry.

After confirming the “In Lo” parameter, the next value shown is “rd Lo”. This is the reading that is shown when the input current is at “In Lo”. The arrow buttons can be used to set the currently highlighted digit and the left hand button (marked “Digit”) can be used to move to the next digit. When the correct value has been entered the right hand button (marked “OK”) can be used to confirm the entry.

Normally the “In Lo” parameter would be set to 0mA (“00.0000”) or 4mA (“04.0000”) depending on the sensor configuration. The “Rd Lo” parameter would be set to “0000.00”.

1.4 Setting up the full range value



Figure 19: Set full range value

To enter the setup for the full range parameters, the 2nd button from the left (marked “Set 2”) must be held in until the display shows first “THEOR”, then “dc A”. After this the display will read “In Hi”, and finally the high input setting in mA. The arrow buttons can be used to set the currently highlighted digit and the left hand button (marked “Digit”) can be used to move to the next digit. When the value is correct the right hand button (marked “OK”) can be used to confirm the entry.

The normal value for the “In Hi” parameter is “20.0000”.

After confirming the “In Hi” parameter, the next value shown is “rd Hi”. This is the reading that is shown when the input current is at “In Hi”. The arrow buttons can be used to set the currently

highlighted digit and the left hand button (marked “Digit”) can be used to move to the next digit. When the correct value has been entered the right hand button (marked “OK”) can be used to confirm the entry.

To display the moisture as a percentage with the sensor set to the default value, set the “rd Hi” value to “0020.00”.

To display the Unscaled value or the temperature set the “rd Hi” value to “0100.00”.

Note: After configuration, return the Calibration Switch to ON.

1.5 Brightness Setting

Once you have the calibration switch in the locked Position

Press the 2nd button from the Left (Set 2) you will see “Bright” Release button and press up and down buttons to change. Press OK to accept.



Figure 20: Brightness settings

Once the setup of the Scalable Current Loop Display is complete, the Hydronix sensor needs to be configured using Hydro-Com Software installed on a PC and connected using an RS485 communication link (for example via a Hydronix Sensor Interface Module or an Ethernet Adapter).

Note: References to Hydro-Com in this user guide refer to software versions HS0099 v2.5.0 and above. For further information please refer to the relevant Hydro-Com user guide. Some screen configurations may be different, however, all sensor settings are still valid.

For wiring and calibration information, please refer to the appropriate user guide for the sensor you are installing in conjunction with the Hydro-Com user guide.

The Scalable Current Loop Display can show one of the available output variables. The most common output will be either the Filtered Moisture Percentage or the Average Moisture Percentage. The selection can be made from the Configuration tab in Hydro-Com as shown in Figure 21.




Figure 21: The sensor configuration page

The sensor analogue output can be scaled to either 0-20mA or 4-20mA depending on the requirements of the installation. By default the sensor has the output set to 0-20mA. This can be changed on the configuration page of Hydro-Com. The Scalable Current Loop Display will need to be configured so that the “In Lo” parameter matches the sensor output setting, see section 1.3 for details.

When the output is set to moisture, the sensor default has the output scaling set so that the minimum (0 or 4mA) is set to 0% moisture and the maximum (20mA) is set to 20%. This can also be changed using the High % and Low % entry fields on the configuration page (Figure 22).

If the sensor is configured to output Filtered/Average Unscaled the scaling is automatically configured so that the minimum (0 or 4mA) is set as 0 Unscaled and the maximum (20mA) is set as 100 Unscaled.




Figure 22: The sensor configuration page with the output High and Low %

1 Equipment Specifications

- Bezel size 48mm high by 96 mm wide (1/8 DIN) / 1.85 Inches high by 3.7 inches wide.
- Panel Cutout 45 mm high by 92 mm wide / 1.77 Inches high by 3.62 Inches wide.
- Case Depth 125 mm including connectors / 4.93 Inches including connectors
- Weight 300 grammes / 0.66 Pounds
- Case Material Black polycarbonate
- Connectors Detachable Screw Terminal connectors
- Environmental storage temperature range -20 to +70°C, non condensing
- Operating temperature range 0 to 50°C, non condensing / 32°F to 122°F
- Front sealed IP65
- Power 11-30 VDC
- Burden 10VA maximum
- Input Signals (bipolar) 0-20mA, 4 to 20mA, 0-10V, 1-5V, 0-5V
- Input Resistance 1 Megohms for voltage, 2 Ohms for current
- Accuracy +/-0.05% of range
- Span tempco 25 ppm/°C
- Zero Tempco 30 ppm/°C
- Excitation voltage 24VDC nominal rated at 60mA.
- Filtering / smoothing Selectable time constants of 0 to 25 seconds.
- A/D conversion Sigma-Delta 10 conversions per second, 50/60Hz rejection
Resolution 1 in 400 000 max. over full range
- Display update rate 10 readings per second
- Display Range (max) -199999 to +199999, depending on available signal level

2 Default Factory Settings

The default factory settings for the 0700 Scalable Current Loop Display are:

	Analogue Current	Display Reading
Low	4mA	0
High	20mA	100

The following tables list the most common faults found when using the display. If you are unable to diagnose the problem from this information, please contact your local distributor or the Hydronix technical support team on +44 (0) 1483 468900 or by email: support@hydronix.com.

Symptom: Display blank

Possible explanation	Check	Required result	Action required on failure
No power	Voltage across power terminals	24v DC present	Check power supply and wiring

Symptom: Display not changing

Possible explanation	Check	Required result	Action required on failure
No analogue input	Current in analogue input circuit	0-20 mA depending on installation	Check analogue output from sensor using Hydro-Com and wiring

1 Document Cross Reference

This section lists all of the other documents that are referred to in this User Guide. You may find it beneficial to have a copy available when reading to this guide.

Document Number	Title
HD0682	Hydro-Com User Guide
HD0678	Sensor Electrical Installation Guide

Index

0-10v mode	16	Theoretical Calibration mode	20
Brightness Setting	22	zero range value	21
Connections	15	loop powered sensor	17
Current modes	16	Mounting	13
Factory Settings	25	PLC current input	16
Hydro-Com	23	PLC voltage input	17
Hydronix sensors	19	Safety	11
full range value	21	Specifications	25
Initial Setup	19	Wiring Advice	15